

# LASSALE SEIKO

Cal. 1E50A

# PARTS CATALOGUE

# Cal. 1E50A



125 930



221 930



231 930



241 930



261 930



271 930



282 930



354 930



383 930



384 930



389 930



491 930



767 930



4001 505



4002 505



4146 505



4216 505



4216 506



4219 505



4239 505



4270 505



4271 504



4408 930



4450 505



Maxell SR512SW



022 342



022 343

2/1

# Cal. 1E50A

## Characteristics

Casing diameter :  $\phi$  8.5 mm  
 Maximum height : 2.6 mm  
 Jewels : 5 j  
 Frequency of quartz crystal oscillator : 32,768 Hz (Hz=Hertz . . . . . Cycles per second)  
 Driving system : Step moter (2 poles)  
 Regulation system : Rotary step switch  
 Train wheel setting

PART NO.	PART NAME	PART NO.	PART NAME
<b>125 930</b>	Train wheel bridge		
<b>221 930</b>	Center wheel & pinion		
<b>231 930</b>	Third wheel & pinion		
<b>241 930</b>	Fourth wheel & pinion		
<b>261 930</b>	Minute wheel		
<b>271 930</b>	Hour wheel		
<b>282 930</b>	Clutch wheel		
<b>354 930</b>	Winding stem		
<b>383 930</b>	Setting lever		
<b>384 930</b>	Yoke		
<b>389 930</b>	Setting lever spring		
<b>491 930</b>	Dial washer		
<b>767 930</b>	Spacer for setting lever axle spring		
<b>4001 505</b>	Circuit block		
<b>4002 505</b>	Coil block		
<b>4146 505</b>	Step rotor		
<b>4216 505</b>	Insulator for battery		
<b>4216 506</b>	Insulator for battery connection (-)		
<b>4219 505</b>	Battery connection insulator		
<b>4239 505</b>	Rotor stator		
<b>4270 505</b>	Battery connection (-)		
<b>4271 504</b>	Battery connection (+)		
<b>4408 930</b>	Circuit Block spacer		
<b>4450 505</b>	Rotary step switch		
011 425	Upper hole jewel for third wheel		
011 425	Upper hole jewel for fourth wheel		
011 425	Lower hole jewel for fourth wheel		
011 503	Lower hole jewel for step rotor		
011 568	Upper hole jewel for step rotor		
<b>022 342</b>	Train wheel bridge screw		
<b>022 342</b>	Setting lever spring screw		
<b>022 342</b>	Battery connection (+) screw		
<b>022 343</b>	Rotary step switch screw		
027 155	Tube for setting lever spring		
027 156	Tube for battery connection (+) screw		
027 159	Tube for rotary step switch screw		
027 771	Minute wheel pin		
027 772	Setting lever pin		
027 773	Hooking pin for yoke spring		
027 774	Tube for train wheel bridge		
Maxell SR512SW	Silver oxide battery		

Part numbers in light letters are not shown in photos.