
## **SERVICE GUIDE CAL. Y482F**

## 1. SPECIFICATIONS

Cal. No. Item  Movement		Y482F	
		Movement size	Outside diameter
Casing diameter	17.8 mm		
Height	2.8 mm		
Time indication		Two hands	
Driving system		Step motor (Load compensated driving pulse system)	
Additional mechanism		Electronic reset switch	
Loss/gain		Monthly rate: Less than 20 seconds at normal temperature range	
Regulation system		Nil	
Measuring gate by Quartz Tester		10-second gate	
Battery		SEIKO SR621SW MAXELL SR621SW SONY SR621SW EVEREADY 364 Voltage 1.55 V Battery life is approximately 2 years.	
Jewels		0 jewel	

## 2. NOTES ON REPLACING MOVEMENT

- 1) Winding Stem (Parts No. 351 112)
  - The winding stem for Y482A/B/C cannot be used with Y482F. Therefore, when replacing the movement of the Y482A/B/C with that of Y482F, be sure to also replace the winding stem with that for Y482F.
  - The type of winding stem is determined based on the design of case and dial. Check the case number and refer to "Casing Parts Catalogue" to choose a corresponding stem.
- 2) How to remove the winding stem
  - Push the indented portion of the winding stem holder (See the upper right figure).
- 3) Hour and minute hands
  - When installing hands, be sure to support the movement directly with a flat solid material (stainless steel plate etc.) and press in the hands.



## 3. VALUE CHECKING

Current consumption

For the whole movement; less than  $1.2 \mu A$