# SEIKO

QUARTZ

Cal.16A

elibre No.	16A		Jewels 5 j	Style Nam	B		
				Maximur Frequen (Hz:	teristics diameter: n height: ncy of quartz co HertzC system: Step n on system: Tri	rystal oscillato 32,7 ycle per seco notor system (	3.95 mm or: 768 Hz nd) (2 poles)
121 160	<b>*</b> • 220 160	<b>v</b> ☆ 225 160	231 160	<b>+</b> <b>⊕</b> 241 160	261 160	<b>6</b> 271 160	® 281 160
<b>pa</b> 282 160	291 160	351 160	<b>~</b> 383 160	384 160	حــ 385 160	386 160	\$ 390 160
<b>%</b> 391 160	<b>9</b> 491 160	<b>•</b> 493 160	+ <b>⊕</b> 701 160	¢ 768 160	4001 160	4002 160	<b>4</b> 4146 00
4216 160	<b>28</b> 4225 160	4239	160 4	<b>24</b> 2 161	4270 160	SEIKO SB-E	01
011 541	011 550 012	Ų	<b>u</b> 6 012 777	2/1			

Calibre No.	16A	Jewels 5 j	Style Name	
PART NO.	PART NAME		PART NO.	PART NAME
121 160 220 160 220 160 225 160 225 161 225 162 231 160 241 160 261 160 271 161 271 162 281 160 281 160 381 160 381 160 381 160 385 160 386 160 390 160 391 160 493 161 493 162 701 160 493 161 493 162 701 160 493 160 493 161 493 162 701 160 493 160 493 161 493 162 701 160 493 160 493 161 493 162 701 160 493 160 493 161 493 162 701 160 493 160 493 161 493 162 701 160 493 160 493 161	Train-wheel bridge Great wheel (with friction pir Cannon pinion (1.52 mm) Cannon pinion (2.02 mm) Cannon pinion (2.02 mm) Third wheel & pinion Fourth wheel & pinion Minute wheel Hour wheel (0.90 mm, Silver) Hour wheel (1.40 mm, Silver) Setting wheel Clutch wheel Intermediate setting wheel Winding stem Setting lever Yoke (Clutch lever) Yoke spring (Clutch lever spring Setting lever spring Setting lever axle Second-setting lever Dial washer Hour wheel ring (0.05 mm thickneel Hour wheel ring (0.10 mm thickneel Fifth wheel & pinion Setting lever axle ring Circuit block Coil block Step rotor Insulator for battery	ring) ickness)	4239 160 4242 161 4270 160 011 541 011 550 011 550 012 107 012 146 012 146 012 146 012 777 SEIKO SB-DI U.C.C.384 U.C.C.392	Rotor stator Plus terminal of battery connection Battery connection Upper hole jewel for step rotor Lower hole jewel for step rotor Upper hole jewel for third wheel Upper hole jewel for fourth wheel Upper hole jewel for fifth wheel Dial screw Circuit block screw Screw for holding spring for battery Screw for plus terminal of battery connection Train-wheel bridge screw Setting lever spring screw SEIKO genuine silver oxide battery Substitutive battery

#### Remarks:

4216 160 4225 160

> There are two different types of the following parts. Combination:

Holding spring for battery


Туре	Cannon pinion	Hour wheel		
a				
	☆225 160 (1.52mm)	☆271 160 (J.90 mm, Silver)		
ь		☆ 27 i 16 i (1.00 mm, Gold)		
c	÷ 225 162 (2.02 mm)	☆271 162 (1.40mm, Silver)		

## TECHNICAL GUIDE

### SEIKO

**QUARTZ** 

**CAL. 16A** 




#### CONTENTS


1.	SPECIFICATIONS AND FEATURES  1. Specifications  2. Features	· 1 1 1
11.	GEAR TRAIN MECHANISM	2
Ш.	HOW TO SET THE TIME	2
IV.	AFTER-SALE SERVICING INSTRUMENTS AND MATERIALS	2
٧.	DISASSEMBLING, REASSEMBLING, LUBRICATING AND CLEANING	3
	1. Case	3
	2. Electronic circuit and gear train mechanism	4
	3. Setting mechanism	6
	4. Cleaning	8
VI.	CHECKING AND ADJUSTMENT	9
	1. Guide table for Checking and Adjustment	9
	2. Procedures for Checking and Adjustment	10
	A. Check output signal	10
	B. Check battery voltage	10
	C. Check battery conductivity	10
	D. Check circuit block conductivity	12
	E. Check reset condition	12
	F. Check coil block	14
	G. Check output signal	14
	H. Check second setting lever condition	14
	I. Check accuracy	14
	Time accuracy adjustment method	16
	Measuring current consumption	16

#### SEIKO Quartz Calibre 16A

The SEIKO Quartz Cal. 16A is a thin and compact quartz crystal oscillator watch providing easy after-sale servicing, which has been made possible through SEIKO's advanced manufacturing techniques and the possible complete electronic systems available today.

Calibre 16A





Movement

Actual size



#### I. SPECIFICATIONS AND FEATURES

#### 1. Specifications

1tem	Calibre No. 16A			
Time indication	2 hands (hour & minute)			
Additional mechanism	Electronic circuit reset switch			
Crystal oscillator	32,768 Hz (Hz = Hertz cycles per second)			
Loss/gain	Loss/gain at normal temperature  Monthly rate: less than 15 seconds  (Annual rate: less than 3 minutes)			
Casing diameter	15.1 mm × 13.0 mm			
Height	3.9 mm			
Operational temperature range	$-10^{\circ}$ C $\sim +60^{\circ}$ C (14°F $\sim 140^{\circ}$ F)			
Driving system	Step motor system (2 poles)			
Regulation system	Trimmer condenser			
Battery power	SEIKO jenuine silver oxide battery SB-D1 Battery life is over 2 years. Voltage 1,5 V			
Jewel	5 jewels			


Remarks: Substitute battery for servicing . . . U.C.C. 392

#### 2. Features

This ladies' dress watch is artistically produced of a craftmanship which is the mode of today. Crystalized in its microcosm, like a tiny shell of about 0.6 cm<sup>3</sup>, are modules of a quartz crystal oscillator, coil block and other functional parts to form a timeless gem which takes on the same touch of elegance and profile as the already proven mechanical watch Cal. 11 (ZW series).


#### II. GEAR TRAIN MECHANISM

- (1) Electric signal is transmitted from the circuit block into the coil block once every 2:5 seconds and the rotor stator becomes magnetized.
- (2) When the rotor stator becomes magnetized, the N and S poles of the rotor stator and the N and S poles of the step rotor alternately repel and attract causing the step rotor to rotate in 180° increments once every 2.5 seconds.
- (3) Rotation of the step rotor is transmitted to the gear train to move the hour and minute hands once every 2.5 seconds.





#### III. HOW TO SET THE TIME

As the special gear train is incorporated with the setting mechanism, it is requested to advance the minute hand from 5 to 10 minutes ahead and turn it back to set the correct time.



#### IV. AFTER-SALE SERVICING INSTRUMENTS AND MATERIALS







Quartz tester, QT-10

Volt-ohm-meter and condenser kit

Movement holder, S-664

#### V. DISASSEMBLING, REASSEMBLING, LUBRICATING AND CLEANING

#### • Disassembling and reassembling

Disassembling procedures Figs.: ① ~ ③ Reassembling procedures Figs.: ③ ~ ①

#### Lubricating

Type of oil:

Moebius A

> SEIKO Watch Oil S-6


Oil quantity: ∞

> Liberal quantity


Normal quantity

Extremely small quantity

#### 1. Case




#### 2. Electronic circuit and gear train mechanism




#### REMARKS FOR DISASSEMBLING AND REASSEMBLING


• When the holding spring for battery is used.



 When the plus terminal of battery connection is used.
 Adjust the plus terminal of battery connection toward the arrow marked direction (Inner side) for holding the battery securely and tighten the screw.




• How to handle the coil block (6)




Hold the coil block by the hole with tweezers.

Fifth wheel

• Position of the second setting lever (7)





train-wheel bridge Crown position: First click

Reset pin

Check to see that the second setting lever (A) touches the fifth wheel and pinion, and that the sacond setting lever (B) is now positioned on the inside the hole of the train-wheel bridge.

**■** Crown position: Normal

Check to see that there is clearance


between the second setting lever

(A) and the fifth wheel and pinion and that the second setting lever (B) is positioned at the side of the hole of the train-wheel bridge.

As the reset pin (part of the circuit block) is inside the hole of the train-wheel bridge, it will touch the second setting lever if it is located inside the second setting lever as shown in illsutration.

Disassemble and reassemble the second setting lever with the crown at the normal position.

Handling of great wheel with friction pinion




- Be sure to lubricate as shown in the illustration.
- The great wheel and friction pinion are frictionally fixed together at arrow-marked position. Do not disassemble them.

-- 4 ---


- 5 -

#### 3. Setting mechanism




#### REMARKS FOR DISASSEMBLING AND REASSEMBLING

- Dial washer 18
   Be careful not to change the original shape of the dial washer.
- Hour wheel ring 19 It is used for adjusting the play of the hour wheel but some models are not provided with the hour wheel ring.
- How to assemble the setting lever spring ② Tighten the arrow-marked screw first.



• Difference between the intermediate setting wheel and the setting wheel 25 26

The setting wheel and intermediate setting wheel are almost the same in shape, but their thickness is different.



• How to assemble the yoke and the yoke spring (28) (29)



Hook the yoke spring on the pin on the reverse of the yoke as illustrated in the left.

### 4. Cleaning


Since several special parts (electronic parts, etc.) used in the SEIKO Quartz 16A differ from conventional mechanical watches, use the following cleaning methods when cleaning.

#### CLEANING METHOD


Name of parts	Cleaning	Drying	Solution	Remarks
Circuit block	DO NOT CLEAN			Conductive portion ONLY may be cleaned with a cloth moistened with benzine or alcohol.  Dry in COOL air.
Coil block				
Rotor stator	Rinse or gently scrub with a brush	Cool air	Benzine	Be careful not to bend the rotor stator.
Step rotor				
				Since the step rotor is magnet, use a clean solution.  Any foreign matter which cannot be removed by cleaning should be removed with adhesive tape or Rodico.
Plastic parts	Rinse or scrub with a brush	Cool air	Benzine or alcohol	
Parts other than the above	Clean with cleaner, rinse or gently scrub with a brush	Cool or hot air	Benzine or trichloro- ethylene	


#### VI. CHECKING AND ADJUSTMENT


#### 1. Guide Table for Checking and Adjustment



#### 2. Procedures for Checking and Adjustment








Time accuracy is adjusted by turning the trimmer condenser.

- Adjustment should be made after ascertaining by the Quartz Tester whether the watch tends to gain or lose.
   The watch gains or loses according to the direction in which the trimmer condenser is turned.
- Note for handling of Trimmer condenser
  - 1. Avoid excessive depressing.
  - 2. Avoid turning the Trimmer condenser unnecessarily.




In cases where a frequent battery change is required, a current consumption test is recommended. Use the following procedures:

- 1. Set up the condenser kit (200  $\mu$ F  $\sim$  500  $\mu$ F) as shown in the photo.
- 2. Range to be used: DC 6 mA



- 3. Place the battery on the metal part of the circuit block with its plus surface down.
- 4. Touch the red and black probes as follows.
  - Probe Red (+)..... Battery connection
  - Probe Black (—) .... Battery surface (—)



5. When the pointer stabilizes, turn the rotary switch to set the current measuring range at DC 0.03 mA and read the current consumption.

(Note: During the measurement, be careful not to detach the probes from the battery and battery connection.)

If the range of the Volt-ohm-meter is set at DC 0.03 mA for measuring the current consumption of the Calibre 16A and when the probe of the Volt-ohm-meter touches the battery connection and the battery, the current consumption will become higher for a while than usual, because an electric signal from the circuit block is generated in order to offset the reversed backlash of the gear train.

Unless the above procedures (1  $\sim$  5) are not followed, the pointer of the Volt-ohm-meter may scale out and it is impossible to measure the current consumption.

All procedures of Disassembling and Reassembling, and Checking and Adjustment are completed.