SEIKO

DIGITAL QUARTZ

Cal. C515A

Cal. C515A







4001 830



4225 830



4246 858



4246 859



4270 795



4293 830



4313 830



4313 831



4398 830



4410 830



4510 825



4521 890



4530 230



☆ Matsushita BR2016

Cal. C515A

Characteristics

Casing diameter:

26.5 imes 25.0 mm

Maximum height:

5.1 mm without battery

Frepuency of quartz crystal oscillater: 32,768 Hz (Hz=Hertz.... Cycles per second)

Time and calendar display: Hour, minute, second and day of the week can be displayed in 12-hour or 24-hour indication.

At the push of a button year, month, date, day and "A"(A.M.)/"P"(P.M.) by key operation.

Calculator display: Can make arithmetic operations and calculation up to 8 digits by pushing the number keys with top of finger. Almost every calculation needed in dayly living is possible.

Numerical display: 2-channel numerical memory up to 8 digits.

Alarm display: Can be set to operate at any desired hour, minute and "A"(A.P.)/"P"(P.M.).

Stopwatch display: Digital display system showing hour, minute, second and 1/100 second up to 10 hours (9 hours, 59 minutes, 59 seconds and 99).

Time signal: Can be set to ring every hour on the hour. Display medium: Nematic liquid crystal, FE-Mode. Regulation system: Trimmer condenser.

Illuminating light: Illuminates all the digital displays in the dark by pushing the light button except for calculator.

PART NO.	PART NAME	PART NO.	PART NAME
4001 830 4225 830 4246 858 4246 859 4270 795 4293 830 4313 831 4398 830 4410 830 4510 825 4521 890 4530 230 (Matsushita BR2016) (Maxell CR2016)	Circuit block Battery clamp Plus lead terminal Buzzer lead terminaf Battery connection (~) Key board switch plate Connector (A) Connector (B) Liquid crystal panel frame Circuit cover Liquid crystal panel Reflecting mirror Bulb Lithium battery		

Remarks:

☆ Matsushita BR2016)

☆ Maxell CR2016 ☆ Sanyo CR2016 The substitutive battery might be added to the applied battery in the future.


......In that case, please refer to separate "BATTERY LIST FOR SEIKO QUARTZ


WATCHES".

TECHNICAL GUIDE

SEIKO DIGITAL QUARTZ

CAL. C515A






CONTENTS

I.	SPECIFICATIONS	1
н.	STRUCTURE OF CIRCUIT BLOCK	1
Ш.	DISPLAY SYSTEM	2
IV.	DISASSEMBLING, REASSEMBLING AND LUBRICATING	3
	1. Disassembling, reassembling and lubricating of the case	3
	2. Disassembling and reassembling of the module	5
V.	CHECKING AND ADJUSTMENT	7
	Check battery voltage	7
	Check battery conductivity	7
	Check current consumption	7
	Check all segments lit up	8
	Check the contact of C-MOS-LSI — Liquid Crystal Panel	8
	Check liquid crystal panel and circuit block	8
	Check accuracy	9
	Check alarm test system	9
	Check alarm condition	9
	Check functioning and adjustment	10
	Check the conductivity of switch components	10
	Check water resistance	10
	Check functioning	10
	Check bulb condition	10

I. SPECIFICATIONS


	Cal. No.	C515A	
Item			
Display medium		Nematic liquid crystal, FEM (Field Effect Mode)	
Liquid crystal driving system		Multiplex driving system	
Display system		 Time and calendar display (12 or 24 hour indication) Calculator function Alarm function Numerical memory function Stopwatch function 	
Additional mechanism		 Alarm test system Hourly time signal Pattern segments checking system Automatic return system Illuminating light 	
Loss/gain		Loss/gain at normal temperature range Monthly rate: less than 15 seconds	
Movement size	Outside diameter	25.0mm (between 3 o'clock and 9 o'clock sides) 26.5mm (between 6 o'clock and 12 o'clock sides)	
	Height	5,2mm	
Regulation system		Trimmer condenser	
Measuring gate by quartz tester		Any gate is available	
Battery		Lithium battery SANYO CR 2016, Maxell CR2016 and Matsushita BR2016 Voltage: 3.0V Battery life is approximately 3 years	

II. STRUCTURE OF CIRCUIT BLOCK



1

III. DISPLAY SYSTEM



IV. DISASSEMBLING, REASSEMBLING AND LUBRICATING


1. Disassembling, reassembling and lubricating of the case

• Disassembling procedures: 1 - 4

• Reassembling procedures: (4) - (1)


Lubricating:

Silicone grease 500,000 c.s.



[Reassembling of key board portion]

It is not necessary to disassemble except for replacement.




- 1) Set the keys on the keyboard gasket. (Fig. 1)
- 2) Set the keyboard gasket with keys to the keyboard.
- 3) Set the keyboard switch plate on the middle.

Note:

Set the keyboard switch plate in the guide groove of the middle stably. (Fig. 2)


- 4) Set the keyboard on the middle.
- 5) Tighten the keyboard screw (6 pcs.)
 *Apply small quantity of rubberized adhesive to prevent the screws from loosening.
 (Fig. 3)




2. Disassembling and reassembling of the module

• Disassembling procedures: 1 – 12 (Remove connector B first.)

• Reassembling procedures: (12) - (1) (Reassemble the connector B last.)



Relationship between the segment (liquid crystal panel electrode) and the C-MOS-LSI output terminal



V. CHECKING AND ADJUSTMENT


The explanation here is particularly for the points of Cal. C515A. Refer to the "TECHNICAL GUIDE, GENERAL

INSTRUCTION" for SEIKO Digital Quartz for details. Procedure **CHECK BATTERY VOLTAGE** Result: • Set up the volt-ohm-meter. Normal': More than 2.8V . Range to be used: DC 6V. Defective: Less than 2.8V **CHECK BATTERY CONDUCTIVITY** CHECK CURRENT CONSUMPTION · Set up the volt-ohm-meter • Range to be used: DC 12μA • Set the condenser kit of 200 \sim 500 μ F. • Check in any function except calculator function. 1) Current consumption of the whole of module . Probe black Result: Normal: Less than 1.3µA Defective: More than 1.3µA Proceed to 2) Probe rec Current supplier \$-833 2) Current consumption of circuit block alone Result: Normal: Less than $1.2\mu A$ Probe black Replace liquid crystal panel Defective: More than 1.2µA Probe red Replace circuit block Current supplier S-833

Procedure

CHECK ALL SEGMENTS LIT UP


Check to see if all segments light up when the buttons "B" and "C" are depressed at the same time in time and calendar setting function.



CHECK THE CONTACT OF C-MOS-LSI - LIQUID CRYSTAL PANEL

CHECK LIQUID CRYSTAL PANEL AND CIRCUIT BLOCK

- Set up volt-ohm-meter
- Range to be used: DC 3V
- How to check the output voltage of circuit block



Result:

Normal: More than 0.8V Defective: Less than 0.8V


Procedure

CHECK ACCURACY

- Mesure the daily rate with all segments displayed by depressing the buttons "B" and "C" at the same time in the time and calendar setting function.
- If the reading is not stable, adjust it by rotating the level adjuster knob of the quartz tester.

CHECK ALARM TEST SYSTEM

• Check to see if the alarm rings when the buttons "B" and "C" are depressed at the same time in time and calendar display.



Result:

Normal: Alarm sounds
Defective: Alarm does not sound
Check alarm condition.

CHECK ALARM CONDITION

• Check up converter coil


Measure the resistance of upconverter coil and check to see if there is any breaking of wire or short circuit.

Set up Volt-ohm meter Range to be used: OHM x 1



Normal : $40 \sim 80 \ \Omega$ Defective: Less than 40Ω

More than 80Ω




Procedure


• Check the output voltage of alarm

Check to see if the output voltage for the alarm is conducted from the circuit block while depressing buttons "B" and "C".

Result:

Normal: The pointer swings slightly Defective: The pointer does not swing





*When there is no defect to be found through the checking methods above, check the piezoelectric element for break, crack, etc.

CHECK FUNCTIONING AND ADJUSTMENT

CHECK THE CONDUCTIVITY OF SWITCH COMPONENTS


CHECK WATER RESISTANCE

CHECK FUNCTIONING

CHECK BULB CONDITION

Note: If the bulb does not light up, it may often be caused by the short circuit made by the bad contact between the leads of bulb and the side switch spring.

Amend by pushing the leads of bulb with tweezers through the side space of liquid crystal panel frame.



All procedures of Disassembling, Reassembling, Lubricating, Checking and Adjustment are completed.