

# RADO

S W I T Z E R L A N D

## SIZING INSTRUCTIONS FOR RUBBER STRAPS



Step 1: Remove plastic from metal buckle



Step 2: Open buckle



Step 3A: Use a push device, such as a small paper clip on the 6 o'clock side of the watch, and insert it into the hole where the spring bar sits connecting the strap and the buckle. It is important to remove the initial selections(s) from the strap section on the 6:00 side of the watch.




Step 3B: (Different Angle)



Step 4: Carefully remove the strap from the buckle



Step 5: Use a tweezer or plier to remove the spring bar from the strap. Take care to not pull the spring bar out by the end, grasp the piece as close to the center as possible



Step 6: Use a sharp scissor or cutting device to cut one section of the strap, making sure to cut as precisely along the indented cutting line as possible.


# RADO

SWITZERLAND


## SIZING INSTRUCTIONS FOR RUBBER STRAPS



Step 7: Cut all the way through the strap section to be removed in a clean straight line



Step 8: Insert the spring bar into the last hole on the strap and push it all the way through until it is centered.



Step 9: Position the bottom of the spring bar into the hole of the clasp and then position the top end evenly with clasp section.

Step 10: Use your pushing tool (i.e. push pin) to push the top end of the spring bar and position it into the top hole of the clasp.

